

5. Download the MirrorOp (Sender) App

• Windows Phone/Windows RT not supported by MirrorOp

1) Make sure your PC/Mac is WiFi-enabled, and connect your PC/Mac to the WiCS-2100 through WiFi. You can find the WiFi network name (SSID) of your WiCS-2100 device on the standby screen of the projector/display. [Default SSID is WiCS-2100-xxx (xxx are the last three characters of the MAC ID shown on the bottom of the WiCS-2100).]

2) Open the browser of your computer, and enter the IP address or the device hostname in the address bar of the browser. You can find the IP address and hostname on the standby screen of the projector/display. [Default IP address is 192.168.100.10; default hostname is WiCS-2100-xxx (xxx are the last three characters of the MAC ID shown on the bottom of the WiCS-2100).]

3) Now you should be able to see the "Home" page. Click the icon to download the portable version of the MirrorOp Sender app for Windows (Windows 7/8/10) or Mac (macOS 10.9 and above). [If you want to know the difference between the portable version and the installed version of the MirrorOp app, please refer to the User's Manual.]



Windows



Mac

6. Start the MirrorOp (Sender) App

• Make sure that the MirrorOp app is not blocked by your firewall.

1) When the MirrorOp app download is complete, double click  on the file to run it. The MirrorOp app will automatically locate the WiCS-2100. (If not, you can click or input the hostname/IP in the text box to connect to the device.)

2) You will see the user interface of MirrorOp. Click  and start sharing your screen.



Windows



Mac

Note:

- See the User's Manual for more information. You can download the User's Manual (PDF file) from <https://www.barco.com/support/wepresent-wics-2100/docs>.
- The MirrorOp (Presenter) app for iOS and Android devices can be downloaded from the Apple App Store or Google Play Store.

Warranty Policy:

For warranty terms and conditions, please visit our website at: <https://www.barco.com/about-barco/legal/warranty-policy>.



wePresent

WiCS-2100

Quick Start Guide | Version: 4.00

