



Scan for full manual

W-45 Quick Start Guide

This guide helps you install and use your **W-45** for the first time.

Go to www.kramerav.com/downloads/W-45 to download the latest user manual.


Step 1: Check what's in the box

- ✓ **W-45** Single Wall Plate Insert
- ✓ 1 Quick start guide
- ✓ 2 M3X5 Flat-head Philips screws


Step 2: Get to know your W-45

W-45 is a Single Wall Plate Insert with one female RJ-45 connector.

Front View



Rear View



Technical Specifications

Input	CAT 6	On a female RJ-45 connector
Output	CAT 6	On a female RJ-45 connector
Environmental Conditions	Operating Temperature	0° to +40°C (32° to 104°F)
	Storage Temperature	-40° to +70°C (-40° to 158°F)
	Humidity	10% to 90%, RH non-condensing
Enclosure	Size	Single insert
	Type	Aluminum
Regulatory Compliance	Safety	CE
General	Net Dimensions (W, D, H)	5.05cm x 2cm x 2.34cm (2" x 0.8" x 0.9")
	Shipping Dimensions (W, D, H)	12.6cm x 8.4cm x 4.1cm (5.5" x 3.3" x 1.6")
	Net Weight	0.02kg (0.04lbs) approx.
	Shipping Weight	0.08kg (0.18lbs) approx.
Accessories	Included	2 M3x5 flat-head Philips screws
Specifications are subject to change without notice at www.kramerav.com		