






	A	B	C	D	E	F	G	H
98QN9*A 98QNA9*	86.0 inches (2185.1 mm) (218.51 cm)	49.2 inches (1249.3 mm) (124.93 cm)	1.2 inches (30.9 mm) (3.09 cm)	51.9 inches (1319.0 mm) (131.90 cm)	14.4 inches (366.9 mm) (36.69 cm)	97.5 inches (247 cm)	135.4 lbs (61.4 kg)	166.9 lbs (75.7 kg)

* : 0~9, A~Z





	VESA A x B (mm)	C (mm)	D x 4
98QN9*A 98QNA9*	600 x 400	11-13	M8

* : 0~9, A~Z


SAMSUNG

QUICK SETUP GUIDE
GUIDE D'INSTALLATION RAPIDE
GUÍA RÁPIDA DE CONFIGURACIÓN
GUIA RÁPIDO DE INSTALAÇÃO
KURZANLEITUNG ZUR KONFIGURATION
GUIDA DI INSTALLAZIONE RAPIDA







USB	USB ↔
OPTICAL	⓪ ↗
ARC	HDMI (eARC)
	HDMI
LAN	LAN
ANT	ANT




1




2




3





4




5




6-1



6-2



7



8

